


JA71-TR131 1.31 in High - Tray Mount Blanking Plate



Installation Manual

Rev. A

Jupiter Avionics Corporation 1959 Kirschner Road Kelowna BC Canada V1Y 4N7 Tel: 778-478-2232

Toll-Free: 855-478-2232 www.jupiteravionics.com



Copyright 2022 Jupiter Avionics Corp.

All rights reserved

Jupiter Avionics Corporation (JAC) permits a single copy of this manual to be printed or downloaded for the express use of an installing agency. Any such electronic or printed copy of this manual must contain the complete text of this copyright notice. Any unauthorized commercial distribution of this manual is strictly prohibited. Except as described above, no part of this manual may be reproduced, copied, transmitted, disseminated, downloaded, or stored in any storage medium for any purpose without the express prior written consent of JAC.

IMPORTANT:

Information in this document is subject to change without notice.

To confirm the current revision status of this manual, visit the JAC website:

www.jupiteravionics.com

RECORD OF REVISIONS					
Revision	Rev Date	Description	ECR		
Α	Aug 2022	Initial release, Serial number 1001 and higher.	6509		

Prepared:	Checked:	Approved:
DGB	JAC 08-03-22 DB	JAC 08-03-22 KDV

Rev A Page ii



Table of Contents

SECTIO	N 1 - DESCRIPTION	1
1.1	System Overview	1
1.2	Features Overview	
1.3	Specifications	
1.3.		
SECTIO	N 2 – INSTALLATION	
2.1	Introduction	2
2.2	Continued Airworthiness	2
2.3	Unpacking and Inspecting Equipment	2
2.3.	1 Warranty	2
2.4	Installation Procedures	
2.4.	1 Mechanical Installation	2
2.5	Installation Kit	2
2.6	Installation Drawings	2
Appendix	x A - Installation Drawings	A1
A1	Installation Drawings	A1

JA71-TR131 1.31 in High - Tray Mount Blanking Plate

SECTION 1 - DESCRIPTION

1.1 System Overview

The JA71-TR131 1.31 in High Tray Mount Blanking Plate (Radio Cover Plate) allows the aircraft owner / operator to remove a piece of radio equipment from the cockpit and fill the void with a compatible sized cover plate. The blanking plate reduces the amount of debris and dust entering the equipment rack. Matching the design and color to existing control heads presents the customer with a professional look and feel to the instrument panel.

1.2 Features Overview

The JA71 is painted with a baked-on urethane finish to resist scratches and nicks during use.

1.3 Specifications

1.3.1 Mechanical Specifications

Height 1.31 in [41.1 mm] maximum

Depth 1.83 in [46.5 mm] maximum

Width 6.31 in [160.3 mm] maximum

Weight 0.27 lb [0.12 kg] maximum

Material 6061-T6XX aluminum

Finish Flat urethane paint finish

Mounting 4 x 6-32 fasteners

Rev A Page 1

JA71-TR131 1.31 in High - Tray Mount Blanking Plate

SECTION 2 – INSTALLATION

2.1 Introduction

This section contains unpacking and inspection procedures and installation information.

2.2 Continued Airworthiness

Maintenance of the JA71-TR131 is on condition only. Scheduled inspection and/or periodic maintenance of this unit is not required.

2.3 Unpacking and Inspecting Equipment

Unpack the equipment carefully. Check for shipping damage and report any problems to the relevant carrier. Confirm that the Authorized Release Certificate or Certificate of Conformance is included. Complete the on-line warranty card from the Jupiter Avionics Corporation (JAC) website – www.jupiteravionics.com.

2.3.1 Warranty

All products manufactured by JAC are warranted to be free of defects in workmanship or performance for 2 years from the date of installation by an approved JAC dealer or agency. This warranty covers the cost of all materials and labour to repair or replace the unit, but does not include the cost of transporting the defective unit to and from JAC or its designated warranty repair centre, or of removing and replacing the defective unit in the aircraft. This warranty does not cover failures due to abuse, misuse, accident, or unauthorized alteration or repairs.

Contact JAC for return authorization, and for any questions regarding this warranty and how it applies to your unit(s). JAC is the final arbiter concerning warranty issues.

2.4 Installation Procedures

2.4.1 Mechanical Installation

The JA71-TR131 can be mounted in any attitude and location. Ensure all fasteners are secured.

2.5 Installation Kit

N/A

2.6 Installation Drawings

The drawings and documents required for installation can be found in Appendix A of this manual.

Rev A Page 2


JA71-TR131 1.31 in High - Tray Mount Blanking Plate

Installation Manual Appendix A - Installation Drawings


A1 Installation Drawings

DOCUMENT	Rev
JA71-TR131 Mechanical Installation	


Rev A Page A1







Installation Panel



6-32 Pan Head Screw

Existing Tray Supports

-6-32 Locking Nut

CENTER OF GRAVITY
±0.03in [0.8mm]

WEIGHT: 0.27 lbs [0.12 kg] MAX.